



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	Comments	PART NUMBER	
1	Damper Assembly		34515	
	Damper Control		13229	
	Damper Weight		19785A	
2	Starter Section Assembly		22072B	
3	Top Standoff	Qty. 4 req	11864i	
4	End Retainer Assembly	Qty. 2 req	13829A	
5	Grate Retainer (for End Retainer Assembly)	Qty. 4 req	13294B	
6	Left Side Ashlip		13827A	
7	Front Door Support		4012-108	
8	Grate		GR3	Y
9	Hearth Refractory		13213A	
10	Front Ashlip		13214A	
11	Back Refractory		27856	
12	Side Door Support	Qty. 2 req	23954	
13	Right Side Ashlip		13828A	
14	Side Refractory	Qty. 2 req	27857	
15	Side Smoke Shield	Qty. 2 req	13238C	
	Air Kit		AK17	
	Plate Assembly		19081A	
	Air Kit Installation Instructions		31168	
	Outside Air Shield		33271	
	Door Track (for bottom)		4012-002	
	Door Track (for top)		15425	
	Fastener Pack		12010B	
	Firescreen Assembly	Qty. 2 req	12267	Y
	Screen Handle		4021-150	Y
	Firescreen Rod	Qty. 2 req	11866B	Y
	Grate Retainer	Qty. 2 req	13834B	
	Nailing Flange	Qty. 4 req	12692	
	Outside Air Door Assembly		13268A	
	Refractory Bracket	Qty. 2 req	13896B	
	Side Refractory Bracket	Qty. 2 req	13831C	
	Strip Protector	Qty. 4 req	18320	
	Touch Up Paint		TUP-GBK-12	
	BAY-40 Installation Instructions and Owner's Manual		34977	