



Part number list on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Damper Blade Assembly		22890	
	Damper Weight		13944B	
	Damper Rod		28900	
2	Starter Section Assembly		22069B	Y
3	Top Standoffs	Qty. 4 req.	11864i	
4	Smoke Shield	Qty. 2 req.	20399	
5	Back Refractory	Qty. 2 req.	27068	
6	Side Refractory	Qty. 4 req.	27067	
7	Firescreen Assembly	Qty. 4 req.	26038	Y
	Firescreen Handle	1 ea.	4021-149	
8	Door Support	Qty. 2 req.	4012-108	
9	Ashlip	Qty. 2 req.	20401	
10	Hearth Refractory		13321B	
11	Damper Control		20549	
12	Grate		GR12	Y
13	Air Kit		AK17	
14	Outside Air Plate Assembly		19081A	
15	Outside Air Shield		33271	Y
	AK17 Installation Instructions		31168	
	Air Kit Fastener Pack		17916B	
	Bottom Door Track (used for upper)	Qty. 2 req.	4012-002	
	Door Track (used for lower)	Qty. 2 req.	15425	
	Firescreen Rod	Qty. 4 req.	11866B	Y
	Gas Access Panel (for use with Air Kit)	Qty. 2 req.	31636	
	Grate Clip	Qty. 2 req.	28062	
	Grate Retainer	Qty. 2 req.	17365D	
	Nailing Flange	Qty. 8 req.	31190	
	Refractory Bracket	Qty. 2 req.	13328	
	Refractory Retainer	Qty. 2 req.	11847	
	Refractory Standoff	Qty. 2 req.	13327D	
	Smoke Deflector	Qty. 2 req.	20603B	
	Strip Protector	Qty. 4 req.	18320	
	Installation Instructions & Owner's Manual		27177	